Video streaming module – QCast



Features

- Friendly interactive setup wizard
- NFC for Quick connection
- Miracast/local content stream out

- I080p(Full HD) 30fps
- Virtual keypad for remote control
- WLAN I In Module (2T2R recommended)

Module Images



Seno Beno	
Octobronical A	

Specifications		
Model Name	QP01	
Part Number	5J.JCK28.A01	
UPC Code	8400460-3205-0	
Color	White	
Wireless Standard	IEEE 802.11a/b/g/n 2T2R single band	
Frequency Band	2.4GHz ISM Band	
CPU	AM8251@500Mhz	
Security	WPA/WPA2	
DRAM	DDR3 256MB, 1Ghz	
NAND	128MB	
Output Resolution	1280x720 default for HDMI/MHL (HDMI Max. up to 1080p@30p by EDID)	
Input	Micro USB	
Output	HDMI or MHL2.0	
Power	DC 5V/1A, through Micro USB port (HDMI) DC 5V/0.9A, through MHL (MHL)	
Video support	Max. 1080p@30p video decode	
LED	Blue LED indication for Power and WiFi status	
Compatibility	Compatible with projectors that include the HDMI connector	
Dimensioin	.31" x .36" x 1.18"	
Weight	1.05 lbs	

System Requirements		
Windows OS	CPU	Dual Core 2 GHz or higher (ATOM not supported)
	Graphic card	Graphic card with 64MBVRAM or above
	OS version	Windows XP SP3, Vista SP2, Windows 7 SP1, Windows 8,
		Windows 8.1
	PC's WiFi	802.IIn (2T2R recommended)
Mac OS	CPU	Dual Core Intel Core i 1.4 GHz or higher (PowerPC not
		supported)
	Graphic card	Graphic card with 64MBVRAM or above
	OS version	Mac OS X 10.8, 10.9, 10.10
	Recommended Models	Mac Book series and iMac series after E/2011
iOS	iOS	iOS 8
	Phone:	iPhone 4~iPhone 5S
	Pad	iPad 2, the new iPad 3rd gen, new iPad 4th gen, iPad mini
Android	Phone/Pad	Android 4.0/4.2/4.3/4.4.2/5.0









What's in the box

QCast Module \times 1, NFC card \times 1, USB cable \times 1 (1M), HDMI extension cable \times 1 (20cm), Quick start guide \times 1 (English version)


* Wireless connection speed is depended on wireless environment. The installation and operation of the QCast may vary by the display device. Also suitable for other display devices, including LCD monitors and TVs.





Step 1: How to setup on the projector


Option I Projector with MHL function



Option 2 Projector with 1.5A power supply function




Option 3 Other Projectors



Step 2: Select Source

Press SOURCE



Select HDMI



Step 3: Module Setup Wizard

3.1 How to use NFC to setup or Searching App from Google play and Apple store



3.4 App features highlight



3.2 Select the user scenario





3.3 Ready to Cast

